



## E80/TX54R

433 MHz. Transmitter

### Technical Specifications:

FREQUENCY	433.920 MHz
CODING	65536
NUMBER OF CHANNELS	4
POWER SUPPLY	1 x CR2032 3V
WORKING TEMPERATURE	-10+55 °C
RANGE	150 meters in open area

### Cloning Transmitters:

1. On the COPY transmitter push the button you want memorize the code together with the opposite button for 5 sec. (The LED blinks for 5 seconds, after it becomes fixed)
2. Hold the button where you want to memorize the code and release the other. (The LED send out 3 long blinks)
3. In the mean time place the ORIGINAL transmitter in front of the COPY and push the ORIGINAL transmitter button you want to copy. (The LED on the COPY transmitter turns on for 1 second and after turns off)

### Clonacion de Transmisores

1. En el transmisor COPY pulsar el botón que desea memorizar el código junto con el botón opuesto durante 5 segundos. (El LED parpadea durante 5 segundos, después se convierte en fijo)
2. Mantenga pulsado el botón que desea memorizar el código y la libere el otro botón (El LED envía 3 parpadeos largos)
3. En ese momento coloque el transmisor original frente a la copia y pulse el botón transmisor original que desea copiar. (El LED en el transmisor COPY se enciende durante 1 segundo y después se apaga)